

Table 1

Sheet size calculator												
HOW WIDE IS YOUR TUNNEL ?												
Tunnel WIDTH in FEET	10	12	14	16	18	21	24	27	29	30	33	
Tunnel WIDTH in METRES	3.1	3.7	4.3	4.9	5.5	6.4	7.3	8.2	8.9	9.2	10.1	
HOW IS YOUR SHEET FIXED AT THE SIDES ?	XLPOLY SHEET WIDTH REQUIRED IN METRES TO COVER YOUR TUNNEL											
Trenched	7.3	7.3	9.2	11.1	11.1	11.1	14	14	14	not pos	not pos	
Base rail	7.3	7.3	7.3	9.2	9.2	11.1	14	14	14	14	not pos	
Mid Rail	7.3	7.3	7.3	7.3	7.3	9.2	11.1	11.1	11.1	14	14	
Tunnel Length	sheet length required to cover your tunnel is calculated as the length of your tunnel + 1 width. Add extra as needed for doors.											
Feet	Metres	XLPOLY SHEET LENGTH REQUIRED IN METRES----- INCLUDING ENDS										
15	5	8	8	9	9	10	11	12	13	13	14	15
20	6	9	10	10	11	12	13	13	14	15	15	16
25	8	11	11	12	13	13	14	15	16	16	17	18
30	9	12	13	13	14	15	16	16	17	18	18	19
35	11	14	14	15	16	16	17	18	19	20	20	21
40	12	15	16	16	17	18	19	20	20	21	21	22
45	14	17	17	18	19	19	20	21	22	23	23	24
50	15	18	19	20	20	21	22	23	24	24	24	25
55	17	20	20	21	22	22	23	24	25	26	26	27
60	18	21	22	23	23	24	25	26	27	27	27	28
65	20	23	24	24	25	25	26	27	28	29	29	30
70	21	24	25	26	26	27	28	29	30	30	31	31
75	23	26	27	27	28	28	29	30	31	32	32	33
80	24	27	28	29	29	30	31	32	33	33	34	35
85	26	29	30	30	31	31	32	33	34	35	35	36
90	27	31	31	32	32	33	34	35	36	36	37	38
95	29	32	33	33	34	35	35	36	37	38	38	39
100	31	34	34	35	35	36	37	38	39	39	40	41
105	32	35	36	36	37	38	38	39	40	41	41	42
110	34	37	37	38	38	39	40	41	42	42	43	44
115	35	38	39	39	40	41	42	42	43	44	44	45
120	37	40	40	41	42	42	43	44	45	46	46	47
125	38	41	42	42	43	44	45	46	46	47	47	48
130	40	43	43	44	45	45	46	47	48	49	49	50
135	41	44	45	46	46	47	48	49	49	50	50	51
140	43	46	46	47	48	48	49	50	51	52	52	53
145	44	47	48	49	49	50	51	52	53	53	53	54
<p>1. Decide how wide your tunnel is - either in feet or metres and select that column.</p> <p>2. Decide fixing method. Where the fixing method row and the tunnel width column meet - that is the width of sheet that you will need.</p> <p>3. Choose your tunnel length from the left hand columns. Where the tunnel length row meets the sheet width column - that is the sheet length you will need.</p>												